

ISSUE

My Wine Saver PRO® is creating foam in my wine.

If your Wine Saver PRO® is creating foam in your wine the issue is most likely originating from the Draw Stem. The following steps will guide you through correcting the issue.

1. Ensure Draw Stem Gasket is properly seated in Tap Head.
2. Ensure Gasket is tightly seated around Draw Stem.
3. Ensure Draw Stem has no nicks, scratches, kinks, or any other blemishes.
4. Ensure Draw Stem is straight when inserted in bottle.

In the event the Draw Stem is not the issue it could be an internal Tap Head leak which would require replacement. Contact a customer service representative for replacement information.

